RM-X2S/X3S

SERVICE MANUAL

SEE ADDITIONAL INFORMATION

US Model
Canadian Model
AEP Model
UK Model
E Model

Specifications

Dimensions	Approx. 43 × 83 × 49 mm (w/h/d) ($1\ ^3/_4 \times 3\ ^3/_8 \times 1\ ^{15}/_{16}$ in.)
Mass	Approx. 70 g (2.47 oz.)
Supplied accessories	Screws (2) Mounting hardware (1) Labels (4) Cramper (1)

Design and specifications are subject to change without notice.

EXPLODED VIEW



Ref. No.	Part No.	Description	Remark
1	1-473-067-31	REMOTE COMMANDER (RM-X2S)	
1	1-473-067-41	REMOTE COMMANDER (RM-X3S)	
2	X-3369-817-1	BRACKET ASSY	
	X-3369-986-1	LABEL (L, D) ASSY (RM-X2S)	
	3-798-417-11	MANUAL INSTRUCTION (ENGLISH, FRENCH, GERMAN, SPANISH, DUTCH SWEDISH, ITALIAN, PORTUGUESE, CHINESE) (RM-X2S)	
	3-798-418-81	MANUAL INSTRUCTION (ENGLISH, FRENCH, GERMAN, SPANISH, DUTCH SWEDISH, ITALIAN, PORTUGUESE, CHINESE) (RM-X3S)	
	3-921-279-01	LABEL (RF) (RM-X3S)	

使用時は添付資料も参照のこと
Refer to the additional documents

ROTARY COMMANDER

SONY®

English
95A0597-1
Printed in Japan

© 1995. 1

9-960-039-11

Sony Corporation
Mobile Electronics Company

Published by Home A&V Products Div.
Quality Engineering Dept.

RM-X2S/X3S

SONY

SERVICE MANUAL

US Model
Canadian Model
AEP Model
UK Model
E Model

SUPPLEMENT-1

File this supplement with the service manual.

Subject : Change of Label and Instruction Manual

(ENG-96007)

Page	Former Type			New Type		
	Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1		X-3369-986-1	LABEL (L,D) ASSY (RM-X2S)		X-3372-070-1	LABEL A (L.D.S) ASSY (RM-X2S)
		3-798-417-11	MANUAL, INSTRUCTION (English/French/ Germany/Spanish/Dutch/Swedish/Italian/ Portuguese/Chinese) (RM-X2S)		3-856-245-11	MANUAL, INSTRUCTION (English/French/ Germany/Spanish/Dutch/Swedish/Italian/ Portuguese/Chinese) (RM-X2S)
					3-856-246-11	MANUAL, INSTRUCTION, INSTALL (English/ French/Germany/Spanish/Dutch/Swedish/ Italian/Portuguese/Chinese) (RM-X2S)

9-960-039-81

Sony Corporation
Personal & Mobile Communication Company

English
96F0480-1
Printed in Japan
©1996.6
Published by Quality Assurance Dept.